成品规格： 10X14cm

⚠ FALL HAZARD

- Infants can fall through a wide leg opening or out of baby carrier.
- Hold your baby closely at all times until all buckles are securely fastened.
- Make sure the baby's legs are positioned on both sides of the seat and the arms are placed through the arm openings.
- Before each use, make sure all buckles are securely fastened.
- Take special care when leaning or walking.
- Never bend at the waist; bend at the knees.
- This baby carrier is designed for use by adults while walking only.
- Minimum age: 3 Months ; Maximum weight: 15kg
- Regularly check that your child is comfortably and securely seated in the baby carrier, especially when using as a back carrier.

⚠ SUFFOCATION HAZARD

- Do not strap the baby too tightly against the body.
- Ensure there is sufficient room for head movement.
- Keep infant's face free from obstructions at all times.
- Never lie down or sleep while carrying the baby in the baby carrier.
- Inspect the baby carrier regularly for any signs of wear and tear.

Find us at:

www.crollababy.com

Crolla Malaysia Crollababy

Superbrands MALAYSIA CONSUMERS' CHOICE AWARD


CROLLA® amber


3-in-1 BABY CARRIER

Manual Guide



CROLLA® amber | PARTS





⚠ WARNING


IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

- Be aware that your balance may be affected by your movement and your child's movement.
- Take care when bending or leaning forward or sideways.
- Do not use the carrier during sports or physical activities.
- Always monitor your child while using the carrier.
- For low-birth-weight babies or children with medical conditions, consult a healthcare professional before use.
- Keep away from hazards such as heat sources and hot drinks.
- Do not use the carrier if any part is missing or damaged.

INSTRUCTION FOR USE

- When using the carrier for the first time, practice before placing the baby in the carrier, or ask someone for assistance.
- Always support the baby with one arm while fastening or tightening the carrier around the body.
- If possible, use a mirror to check and make final adjustments to the carrier and baby for a snug fit.
- Ensure the baby is secure and comfortable. The carrier should not be too loose or too tight, and should not obstruct the baby's breathing.

HOW TO LOCK & UNLOCK THE ZIP




IMPORTANT:
Always lock the zipper to prevent it from opening during use.

FRONT CARRYING POSITION (FACING IN)

Minimum Age: 3 Months
Maximum Weight: 15 kg / 33 lb

1. Loosen all straps before putting on the carrier.
2. Adjust the seat height by zipping the inner zipper (13) to create a narrow seat. After adjustment, securely lock the zipper in place.




3. Fasten the back support buckle (10) securely, then adjust it up or down to the desired height.
4. Put on the carrier by placing it over your head and putting your arms through the openings.
5. Fasten the waist belt buckle (15) securely then tighten it.
6. Pull the straps attached to the back support buckle (10) to tighten the shoulder pads and lower straps (12) for a secure fit.
7. Adjust the leg opening (6) by unzipping the outer zipper located above the waist belt to provide a suitable width for the baby and support an ergonomic M-position.
8. Fasten the left-side buckle (5) and magnetic buckle (2). Keep the right-side buckles open to allow the baby to be placed into the carrier.
9. Place the baby in the carrier, ensuring the baby is seated securely with both legs positioned through the leg openings and both hands in the correct position. Support the baby snugly against your body with one hand, then fasten the right-side buckle (5) and magnetic buckle (2). Make sure each buckle is securely fastened before releasing your hand from the baby.
10. Tighten the shoulder buckle straps (2).
11. Note 1: Make sure the baby is seated snugly in the carrier, with each leg securely positioned in its own leg opening. If the leg openings are too wide, fasten the loop (7) to the leg opening button (8) to ensure a secure fit.
12. Note 2: Make sure the baby's arms are through the arm openings.
13. Note 3: Before letting go of the baby, make sure all buckles are securely fastened.
14. The carrier is ready for use.

FRONT CARRYING POSITION (FACING OUT)

Minimum Age: 6 Months
Maximum Weight: 15 kg / 33 lb

1. Loosen all straps before putting on the carrier.
2. Insert the sleeping hood (3) into the zipper pouch of the folded head support. Make sure the buttons are unfastened. Unbutton the leg openings and adjust the seat height by unzipping the inner zipper (13) to create a deeper seat.




3. Fasten the back support buckle (10) securely, then adjust it up or down to the desired height.
4. Put on the carrier by placing it over your head and putting your arms through the openings.
5. Fasten the waist belt buckle (15) securely then tighten it.
6. Pull the straps attached to the back support buckle (10) to tighten the shoulder pads and lower straps (12) for a secure fit.
7. Adjust the leg opening (6) by slightly zipping the outer zipper located above the waist belt to provide a suitable width for the baby and support an ergonomic M-position. After adjustment, securely lock the zipper in place.
8. Fasten the left-side buckle (5) and magnetic buckle (2). Keep the right-side buckles open to allow the baby to be placed into the carrier.
9. Place the baby in the carrier facing outward, ensuring the baby is seated securely with both legs positioned through the leg openings and both hands in the correct position. Support the baby snugly against your body with one hand, then fasten the right-side buckle (5) and magnetic buckle (2). Make sure each buckle is securely fastened before releasing your hand from the baby.
10. Tighten the shoulder buckle straps (2).
11. Note 1: Make sure the baby is seated snugly in the carrier, with each leg securely positioned in its own leg opening. If the leg openings are too wide, fasten the loop (7) to the leg opening button (8) to ensure a secure fit.
12. Note 2: Make sure the baby's arms are through the arm openings.
13. Note 3: Before letting go of the baby, make sure all buckles are securely fastened.
14. The carrier is ready for use.

BACK CARRYING POSITION

Minimum Age: 8 Months
Maximum Weight: 15 kg / 33 lb

1. Loosen all straps before putting on the carrier.
2. Adjust the seat height by unzipping the inner zipper (13) to create a deeper seat. After adjustment, securely lock the zipper in place.



3. Adjust the leg opening (6) by fully zipping the outer zipper located above the waist belt to provide a suitable width for the baby and support an ergonomic M-position. After adjustment, securely lock the zipper in place.
4. Fasten the two upper head support (4) buttons to use the head support.
5. Put on the carrier like a backpack and wrap the waist belt around your waist. Fasten the waist belt buckle (15) securely, then pull both sides to tighten.
6. Fasten the chest support buckle (10) securely, then adjust it up or down to the desired height. Pull the straps to tighten the shoulder pads (1) and lower straps for a secure fit.
7. Fasten Buckle (5) and Magnetic Buckle (2) on the left side before placing the baby in the carrier. Ask a second person to place the baby on the carrier's seat while supporting the baby with both hands. Make sure the baby's legs and arms are positioned correctly.
8. Reach behind and support the baby securely with both hands while the second person fastens the remaining Buckle (5) and Magnetic Buckle (2) on the right side, one at a time. Make sure each buckle is securely fastened before releasing support from the baby.
9. Note 1: Make sure the baby is seated snugly in the carrier, with each leg securely positioned in its own leg opening. Fasten the open leg opening buckle and adjust it to ensure a secure fit around the baby's leg.
10. Note 2: Make sure the baby's arms are through the arm openings.
11. Note 3: Before letting go of the baby, make sure all buckles are securely fastened and the baby is seated securely, the baby's face and airway are clear.
12. The carrier is ready for use.

IMPORTANT

- The baby must face you until they can hold their head upright independently.
- Do not use the baby carrier when balance or movement is affected by exercise, drowsiness, or a medical condition.
- Never use the baby carrier while driving or riding in a motor vehicle.
- Never use the baby carrier while cooking, cleaning, or doing activities involving heat sources or exposure to chemicals.
- The baby carrier is NOT suitable for use during sports or other leisure activities.
- Before each use, check that all buckles, snaps, straps, and adjustments are securely fastened.
- Before each use, check for ripped seams, torn straps or fabric, and damaged fasteners.

WASHING INSTRUCTION



Spot clean preferred.



Hand wash preferred.



Hang-dry only.



Wash the product alone and avoid soaking in water.



Machine wash or dry cleaning is not recommended.



No bleach, fabric softener or iron